



Installing a RocketRAID Driver on Microsoft Windows 8

User's Guide

**Revision: 1.0
Nov. 2, 2012
HighPoint Technologies, Inc.**

Copyright

Copyright © 2012 HighPoint Technologies, Inc. This document contains materials protected by International Copyright Laws. All rights reserved. No part of this manual may be reproduced, transmitted or transcribed in any form and for any purpose without the express written permission of HighPoint Technologies, Inc.

Trademarks

Companies and products mentioned in this manual are for identification purpose only. Product names or brand names appearing in this manual may or may not be registered trademarks or copyrights of their respective owners. Backup your important data before using HighPoint's products and use at your own risk. In no event shall HighPoint be liable for any loss of profits, or for direct, indirect, special, incidental or consequential damages arising from any defect or error in HighPoint's products or manuals. Information in this manual is subject to change without notice and does not represent a commitment on the part of HighPoint.

Notice

Reasonable effort has been made to ensure that the information in this manual is accurate. HighPoint assumes no liability for technical inaccuracies, typographical, or other errors contained herein.

Table of Contents

Consider the following before you install the driver	4
Perform the following steps to install the Windows 8 driver	4
Thank You	7
Customer Support.....	8

Consider the following before you install the driver:

- If you want to use the RocketRAID controller for primary storage you will need to make sure the bootable partition is less than 2TB. You will need to have the Windows 8 driver put on a USB, CD disc, or DVD disc.
- If you want to use the RocketRAID controller as secondary storage download the latest drivers from the HighPoint website and follow the steps below.

Perform the following steps to install the Windows 8 driver.


1. Boot the Microsoft Windows 8 OS and then move the mouse to the upper or lower-right corner of the screen to expose the desk icons for Search, Share, Start, Devices and Settings:

Figure 1: Settings Options



2. Click on **Settings**.
3. On the Settings Bar, click on Control Panel.


Figure 2: Settings Menu



4. In the Control Panel, click **Hardware and Sound**:
Figure 3: Hardware and Sound Selection:




5. In Hardware and Sound, click Device Manager under the heading Devices and Printers.
Figure 4: Device Manager



- In the Device Manger, expand the sub-menu under Storage Controllers and right-click **Update Driver Software**.

Figure 5: Update Driver Software Option



- In the Update Driver Software wizard, select Browse My Computer to locate the updated driver.
- When the driver is found, click **Install** to confirm.

Figure 6: Install Button



- The installation wizard presents progress screens and announces the completion of the installation.
- After the driver is installed, reboot the system.

Thank You

Thank you for purchasing HighPoint product. We appreciate your support, and welcome any questions, comments or product suggestions you may have.

Customer Support

If you encounter any problems while utilizing RocketRAID series host adapters, or have any questions about this or any other HighPoint Technologies, Inc. product, feel free to contact our Customer Support Department.

HighPoint Technologies, Inc. websites:

<http://www.highpoint-tech.com/>

Web Support:

<http://www.highpoint-tech.com/websupport/>